


# DISPLAY TROUBLESHOOTING

## Warning:

MDG Computers Canada recommends that you have your system serviced by a professional technician either at one of our stores or by sending your system back to the head office. If you choose to continue the process, be advised that MDG Computers Canada cannot be liable for any loss or damage that may occur.

## How to setup Display Properties

1. Click on **START**
2. Click on **CONTROL PANEL**
3. Make sure that your **CONTROL PANEL** is set to "**CLASSIC VIEW**"
4. IF it is not then on the left hand corner please select "**SWITCH TO CLASSIC VIEW**"
5. It should look like this.




6. Then double click on the **DISPLAY**
7. A screen appears




8. To setup your desktop background click on **DESKTOP** tab on top



9. Here you can change the background, and position it. Whether you would like to use Stretch (to fill the whole screen) or Tile or Center.
10. To set your Screen Saver select the **SCREEN SAVER** tab on top.



11. This is where you would change your Screen saver, the settings for certain screen savers as well as your Power options (such as monitor and hard drive and when they shut off, or after how long).
12. Click on **SETTINGS** tab on top after you are done setting this up.



13. This is where you set your Screen Resolution, and your Color Quality. IF YOU can not change the screen resolution or Color Quality you need to download the latest drivers for your video card.
14. Please note that LCD-TFT Displays and Laptop displays should be running at their native (highest) resolution, otherwise the picture may look very poor.